

Sentinel & Sentry Auto Launch

For Diamond Shipments

The Sentinel temperature monitor with Sentry In-Transit is used for Diamond Shipments


1

Collect Sentinels for shipment. Press the button to ensure **green** LED. If not green, press and hold until flashing green and release.
 Keep Sentinels <30m to Sentry 600 Gateway > 15 min



2

- a. Login to az.ccis.se
- b. Select "Cloud Launch"




3

- a. Scan SAP QR code
- b. Scan Sentinel QR code or type in Sentinel id's



4

- a. Verify correct number of id's listed
- b. Click "Launch"



5

Sentry600 In-transit must have been charged >15 hours before use



6

Check on the display power is on, and the monitor is switched on before attaching it to the pallet



7

Attach both to shipment. The Sentinel and Sentry600 In-Transit contain lithium batteries. Please follow local procedures.



Placement of temperature monitors on the product is outlined in the AZ Quality and Compliance Manual procedure 8-P27