

Launch Sentinel

1

Prepare launch


Collect the Sentinel(s) for the shipment. Ensure green led on button press, see note above.
Keep Sentinel <30m to Sentry gateway >15 min.



2

Login to CCIS

Login to az.ccis.se
Select *Cloud Launch* tab in in top menu.



3

Select Profile

Select profile in drop-down list.

Launch

SELECT PROFILE

4

Enter Logger ID(s)

Scan or type the logger IDs to CCIS. Ensure correct ID(s) captured.



5

Triptags

Review the Triptags, ensure Country of origin, Origin, Country of destination, Destination, Shipment Number and that other Triptags are correctly entered.

6

Launch & Start logger

Click *Launch* to launch Sentinel(s) to shipment. CCIS will respond a successful launch messages.



Note:

- **Step 4&5:** Verify all logger IDs, trip tags and the shipping number are entered correctly (step 4 & 5).
- **Step 6:** If you use a profile with no start delay the monitor/s will start recording immediately when you press the green **Launch button**.
- Where a predefined profile start delay is used or a start time is entered into Cloud Launch the sending site MUST ensure the start time is before the dispatch time
- After Cloud Launch, attach the logger(s) securely to the pallet(s) inline with AZ Global Standard SOP-0033730