

TempViaNet

Administrative User Guide

Version 1.0

TSS AB | Berzelius väg 25-27, 171 65 Solna, Sweden | E-mail: customer.service@tss.se | Phone: +46 (0) 8 630 0606 | www.tss.se



TempViaNet

TempViaNet (TVN) is the central access point to worldwide shipment data. All launched and downloaded temperature data in TTC Web are instantly accessible from TVN. It is for example possible to analyze shipments per destination, within a defined time period, or by temperature levels.



1. Start

TempViaNet has a start page called START where the recent 20 shipments and the 20 recent shipments out of range are shown.

COLUMN 1	viaNet'	Mladenovic, Marina AstraZeneca / TSS CONTROL OFFICE (START	SEARCH
Recent S	Shipments		Recent Shipment	s out of Range		
# Id	Origin	Origin E-Mail Shipping #	# Id Origin	Origin E-Mai	Shipping #	
1. 29293	89 AZ Biologics (Fr	WHSE7840	1. 2929423 West Ch	ester AZ	pb2846-1	
2. 29408	77 Movianto OSS	210176194	2. 2903209 Macclesf	ield AZ	88976533	
3. 29408	79 Movianto OSS	210176194	3. 2932769 Yusen Ar	ntwerp	21007269	
4. 29408	81 Movianto OSS	210176194	4. 2932771 Yusen Ar	ntwerp	210078711	
5. 29408	83 Movianto OSS	210176194	5. 2936021 AZ Biolo	gics (Fr	SR-3390	
6. 29408	85 Movianto OSS	210176194	6. 2939433			
7. 29408	87 Movianto OSS	210176194	7. 2928373 AZ Biolo	gics (Fr	SR-3354	
8. 29408	89 Movianto OSS	210176194	8. 2935259 West Ch	ester AZ	22-REQ-084	
9. 29408	91 Movianto OSS	210176194	9. 2896457 Yusen Ar	ntwerp	925629A US SEA	
10. 29408	93 Movianto OSS	210176194	10. 2896459 Yusen Ar	ntwerp	925629A US SEA	
11. 29408	95 Movianto OSS	210176194	11. 2932847 North Ry	/de AZ	800696225	
12. 29408	97 Movianto OSS	210176194	12. 2932849 North Ry	/de AZ	800696225	
13. 29408	99 Movianto OSS	210176194	13. 2934123 Avantor	Sample Shipm	ient	
14. <mark>2940</mark> 9	01 Movianto OSS	210176194	14. 2932471 Movianto	0 OSS	210112701	
15. 29409	03 Movianto OSS	210176194	15. 2932469 Movianto	0 OSS	210112701	
16. 29409	05 Movianto OSS	210176194	16. 2935729 Indonesi	ia AZ	ID08032201	
17. 29409	07 Movianto OSS	210176194	17. 2929241 Yusen Ar	ntwerp	210014346	
18. 29409	09 Movianto OSS	210176194	18. 2938563			
19. 29409	11 Movianto OSS	210176194	19. 2938555			

2. Search

Search in the database to retrieve shipments based on for example alarms, time period, root causes. There are default settings in the **Basic search**, that you can change and apply before entering your search



criteria. You have the option to include/ignore alarms, pending monitors, devices, root causes and change the time interval.

If you would like to see monitors that have **not** yet been stopped – please make sure to update the drill down to Include Pending (see picture below).

Basic Search	Advanced Search		
Ignore Alar	ms	\sim	0
Include per	\sim	0	
3 Months		~	0
3 Months All TempTra	icers	× ×	0
3 Months All TempTra Ignore prim	icers hary root cause	< <	0 0 0
3 Months All TempTra Ignore prim Ignore seco	acers hary root cause ondary root cause	< < <	0 0 0

Simply mark if the below options should be 'Yes' or 'No' and click on the 'Apply' button.

Ignore Alarms V Image: Alarms of the second se	
All TempTracers V Image: Constraint of the second and the second	Ignore Alarms V Don't include pending V 3 Months O All TempTracers O Ignore primary root cause O Ignore secondary root cause O Ignore product name O

You are now ready to search in Filter:

Basic Search	Advanced Search									
							Search Options			
Ignore Alarr Don't includ 3 Months All TempTra Ignore prim Ignore seco Ignore prod	ms le pending cers lary root cause ndary root cause uct name	 > ><	0 0 0 0 0 0	AII	Yes 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	No 0 0 0 0 0 0	 Find Humidity Find Edited TripTags Evaluated Reports Filtered Reports Has milestones Has root causes Has shipping no 		Apply Clea	r
Filter: Type	to filter							Select/Deselect all	Show Selected Reports Export	•
Origin	Origin E	Ма	ail	÷	Shippir	ig #	Unit Serial Number	🔶 Configura	tion Date (UTC)	♦

You can search for a unit serial number or any kind of identification that is available on the Temperature Graph report. You might select/deselect all rows available within your search criteria or select one only. Click on Show Selected Reports or **Export** (data will be exported to excel or viewed in pdf). **Advanced Search** makes it possible to create and store search criteria profiles.



								l	- Cysten
lemp <mark>Via</mark> Net [®]	Mladenovic, AstraZeneca	, Marina a / TSS COI	NTROL O	FFICE	0		START	SEARCH	CLOSE
Basic Search Advanced Search									
					Hide Search Options				
Ignore Alarms Don't include pending 3 Months All TempTracers Ignore primary root cause Ignore secondary root cause Ignore product name		AII (*) (*) (*) (*) (*) (*) (*) (*)	Yes 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	N0 ○ ○ ○ ○ ○ ○ ○ ○	 Find Humidity Find Edited TripTags Evaluated Reports Filtered Reports Has milestones Has root causes Has shipping no 				Clear
Saved Search: Select a St Origin Search	Reset S	criteria earch & S	Save	✓ D ✓ Eq	elete Selected Criteria	Search	~		

You have the option to choose fields visible in the GxP Graph reports below and create your own advanced search criteria profile.

Saved Search: ዐ	Select a Stored Search Criteria 🗸 🗸	Delete Selected Criteria	
	Origin 🗸	Equals V	Search 🗸
	Origin Origin Origin Origin E-Mail Origin E-Mail Country of Origin Destination Destination Country of Destination Shipping # Delivery # Order # AWB # Type of Transportation Freight Forwarder Carrier Product Customer		
	Package # TempTracer Location Pallet # Notes Mission Start Date (UTC) Average Temperature		
Saved Search: 🛈	Select a Stored Search Criteria	Delete Selected Criteria	
	Origin V	Equals V	Search 🗸
	Search Reset Search & Save	Average Greater Than Less Than Contains	
Saved Search: ዐ	Select a Stored Search Criteria 🗸 🗸	Delete Selected Criteria	
	Origin 🗸	Equals V	Search 🗸
	Search Reset Search & Save		And Or

For example, if you would like to search for a specific product; you choose Product in the first dropdown, equals in the second dropdown and the name of the product in the empty search field. Click on Search to generate your criteria.